

SAFETY WARNING

- 1-ALWAYS WEAR EYE PROTECTION
- 2-PLACE KEY SWITCH IN THE OFF POSITION
- 3-SET PARKING BRAKE.

INSTALLATION INSTRUCTIONS FOR ADAPTER EP-008C YAMAHA MODEL YDRE 2006

- 1-IF CART IS EQUIPPED WITH BUMPER,BUMPER MUST BE REMOVED PRIOR TO INSTALLATION.

- 2-TOOLS NEEDED (ONE) 9/16 SOCKET AND (ONE) 9/16 WRENCH.

HARDWARE INCLUDED (2-BOLTS 3/8"X1 1/2")(2-NUTS 3/8")
(2-WASHERS SPLIT 3/8")

- 3- SLIDE ADAPTER ALONG BOTTOM THEN UP UNTIL HOLES LINE UP THEN PLACE BOLTS AND NUTS AS SEEN ON THE ILLUSTRATION BELOW.

